





Návod k použití



FA14

Před použitím si pečlivě přečtěte tento návod. Dbejte na to, abyste jej používali v přísném souladu s požadavky uvedenými v návodu, a návod řádně uschovejte pro budoucí použití.

Popis vzhledu



- ① Výstup vzduchu
- ② Tlačítko zapnutí/rychlosti
- ③ Světýlko indikátoru
- ④ Vstup vzduchu
- ⑤ Vstup typ-C

Pokyny před použitím

1. Před zapnutím zkontrolujte, zda výrobek a napájecí kabel nejsou poškozeny, ujistěte se, že jsou v dobrém stavu, a sestavte je podle návodu.
2. Před nabíjením výrobku zkontrolujte, zda napětí použitého napájecího zdroje odpovídá štítku výrobku.

3. Výrobek nerozebírejte, neopravujte ani neopravujte, abyste předešli úrazu elektrickým proudem a požáru, a požádejte o opravu servisní středisko určené původním prodejcem nebo výrobcem.

Použití


A. Jak ji používat

Jemně roztáhněte lopatky ventilátoru doleva a doprava, přičemž výstup vzduchu směřuje nahoru, zavěste si jej kolem krku, stiskněte tlačítko napájení/rychlosti a ventilátor začne pracovat, vyfukuje chladný vzduch směrem k vaší hlavě a poskytuje osvěžující zážitek.



B. Přepínač napájení/rychlosti

Krátkým stisknutím tlačítka napájení/rychlosti procházíte režimem prvního stupně/druhého stupně/třetího stupně/čtvrtého stupně/pátého stupně/vypnutí; dlouhým stisknutím na kterémkoli stupni se ventilátor přímo vypne.



C. Stav indikátoru

Indikátor	Význam
Bílé světlo stále svítí	Plně nabitý stav
Bílé světlo pomalu bliká	Stav nabití
Bílé světlo blikne jednou	Přepínání rychlostí
Bílé světlo stále bliká	Baterie je příliš vybitá
Bílé světlo blikne třikrát	Baterie je vybitá a nemůže fungovat

D. Čištění výrobku

1. Před čištěním výrobku se ujistěte, že je odpojeno napájení.
2. Otřete tělo ventilátoru a výstup vzduchu suchým hadříkem.
3. Nikdy nečistěte elektrické součásti (např. motor, vypínač atd.) vodou nebo jinými tekutinami.
4. Nedotýkejte se napájecího zdroje a elektrických součástí mokřýma rukama nebo mokřým hadříkem.
5. Včas uklidte prach nebo cizí předměty ve výstupu vzduchu, abyste zabránili vniknutí prachu do vzduchové dutiny.


Vyjmutí baterie

Před likvidací výrobku je nutné baterii z výrobku vyjmout. Před vyjmutím baterie musí být výrobek vypnutý. Baterie by měly být bezpečně zlikvidovány v souladu s předpisy místa prodeje.

1. Pomocí nástroje odstraňte zátku a spodní šroub, poté otevřete vnitřní kryt a vyjměte spodní šroub (Obrázek 1).
2. Pomocí nástroje vypáchte vnější kryt (Obrázek 2).
3. Vytáhněte konektor baterie a vyjměte baterii, bezpečně ji zlikvidujte v souladu s místními předpisy (Obrázek 3).



Obrázek 1



Obrázek 2



Obrázek 3

Bezpečnostní upozornění

Abyste zajistili bezpečnost používání a předešli zranění a škodám na majetku vás i ostatních, dodržujte následující bezpečnostní opatření. Nesprávné použití bez dodržení bezpečnostních upozornění může vést k nehodám.

01. Tento výrobek není dětská hračka, zajistěte, aby si kojenci a děti nehráli s tímto výrobkem jako s hračkou. Děti mladší 14 let jej musí používat pod dohledem rodičů.

02. Tento výrobek není určen k používání uživateli (včetně dětí) s nedostatečnou fyziologií, vnímáním, mentálními schopnostmi, zkušenostmi nebo znalostmi, pokud jej nepoužívají bezpečně pod dohledem nebo s vědomím osoby odpovědné za jejich bezpečnost.

03. Nefoukejte přímo na lidské tělo po delší dobu, zejména u starších osob a dětí, abyste předešli fyzickému nepohodlí.

04. Při používání nepřikládejte prsty, ostré předměty a kovové předměty apod., které by mohly způsobit selhání výrobku a riziko úrazu elektrickým proudem nebo zranění.
05. Při používání zabraňte použití vlhkých rukou, mokrých ručníků a jiných zástrček, aby nedošlo k úrazu elektrickým proudem.
06. Tento výrobek není vodotěsný, nepoužívejte vodu k přímému oplachování výrobku nebo v koupelně, silné vlhkosti, místech pro skladování vody k použití. Povrchovou vodu před pokusem o zapnutí použití prosím včas vysušte. Zcela nasáklé a s vodou uvnitř nepoužívejte.
07. Nezakrývejte výstup a přívod vzduchu, například zavěšené oblečení, ručníky, oděvy a další předměty, aby nedošlo k selhání výrobku.
08. Zakažte používání a skladování v prostředí s vysokou teplotou (vyšší než 60 °C) a v uzavřených prostorách, jako jsou skleníky, staveníště, krby, exponované prostory automobilů a další prostředí, které způsobí deformaci plastu, plamen s větrem způsobí požár, výbuch baterie a další poruchy a nehody.
09. Baterii nestlačujte, nerozebírejte a neumísťujte na delší dobu do prostředí s vysokou teplotou (60 °C a více), jinak hrozí nebezpečí úniku kapaliny nebo výbuchu.
10. Pokud spotřebitelé používají k nabíjení napájecí adaptér, vstupní jmenovité napětí a proud napájecího adaptéru by měly být v rozmezí 5,0 V/2,0 A a před použitím by měly být splněny povinné národní bezpečnostní certifikace.
11. Tento výrobek používá lithium-iontovou baterii, nemá paměťovou funkci, přebíjení nebo nadměrné vybíjení ovlivní životnost výrobku, nabíjejte včas a po úplném nabití odpojte napájení. Pokud zařízení dlouhou dobu (více než 3 měsíce) nepoužíváte, prosím, plně nabíjete.
12. Pokud se při používání vyskytne kouř, požár a jiné poruchy, okamžitě vypněte napájení, abyste přestali přístroj používat, a pošlete jej prodejci nebo výrobci k řešení, sami jej nerozebírejte, abyste předešli nebezpečí.
13. Během nabíjení neohýbejte ani netahejte za napájecí kabel, aby nedošlo ke špatnému kontaktu.

Parametry produktu

Značka: JisuLife

Model: FA14

Název produktu: Neck Fan Life3

Příkon: 5.0/ 2.0A

Kapacita baterie: 4000 mAh (14,8Wh/3,7V)

Bateriový článěk: Lithium-iontová baterie

Doba nabíjení: 3,5 - 4,5 h

Provozní doba: 2 - 13,5 h (v závislosti na různém vybavení/působu použití)

Hmotnost výrobku: přibližně 270 g

Velikost výrobku: 206 × 200 × 60 mm

Obsah balení

Neck Fan Life3 x1

Napájecí kabel USB-C x1

Manuál x1

Obsah této uživatelské příručky a technické specifikace výrobku se mohou měnit bez předchozího upozornění.

Dodavatel/Distributor

Sunnysoft s.r.o.

Kovanecká 2390/1a

190 00 Praha 9

Česká republika

www.sunnysoft.cz

Výrobce: Shenzhen Jisu Technology Co., Ltd

Address: 301, Building A, No.8, Changjiangpu 2 Road, He'ao Community, Yuanshan Street, Longgang District, Shenzhen

URL: www.jisulife.com

Tel: 400-011-8812




User Guide



FA14

Please read this manual carefully before use. Be sure to use it in strict accordance with the requirements of the manual, and keep the manual properly for future use.

Appearance Description



Air Outlet - - - - - ①
Switch/Gear Button - - - - - ②
Indicator Light - - - - - ③

Air Inlet - - - - - ④
Type-C Input Port - - - - - ⑤

Precautions Before Use


1. Please check the product and power cord for any damage and make sure they are in good condition and assemble them according to the instructions before powering them on.
2. Before charging the product, please check whether the voltage of the power supply used is consistent with the product label.

3. Please do not disassemble, modify or repair the product to avoid electric shock and fire accidents, and ask the service station designated by the original seller or manufacturer for repair.

How To Use


A. How To Use It

Gently spread the fan blades left and right, with the air outlet facing upwards, hang it around your neck, press the power/speed button, and the fan starts working, blowing cool air towards your head, providing a refreshing experience.



B. Power/Speed Switch

Short press the power/speed button to cycle through the first gear/second gear/third gear/fourth gear/fifth gear/shut-down mode; long press at any gear to shut down directly.



C. Indicator Status Description

Indicator Status	Meaning
White light always on	Fully charged state
White light flashes slowly	State of charge
The white light flashes once	Gears switching
White light keeps flashing	Battery is too low
White light flashes 3 times	Battery low and cannot work


D. Product Cleaning

1. Before cleaning the product, please make sure the power is disconnected.
2. Wipe the fan body and air outlet with a dry cloth.
3. Never clean electrical components (such as the motor, power switch, etc.) with water or other liquids.
4. Do not touch the power supply and electrical parts with wet hands or wet cloth.
5. Please clean up the dust or foreign objects in the air outlet in time to avoid dust falling into the air cavity.


Remove The Battery

The battery must be removed from the product before disposing of the product; The product must be powered off before removing the battery; Batteries should be safely disposed of in accordance with the regulations of the place of sale.

1. Use a tool to remove the screw plug and the lower screw, then pry open the inner casing and remove the lower screw (Figure One).
2. Use a tool to pry open the outer casing (Figure Two).
3. Pull out the battery connector and remove the battery, dispose of it safely in accordance with local regulations (Figure Three).



(Figure One)



(Figure Two)



(Figure Three)

Safety Precautions

To ensure the safety of use and to avoid injury and property damage to you and others, please observe the following safety precautions; Incorrect use without observing the safety warnings may lead to accidents.

01. This product is not a child's toy, please ensure that infants and children do not play with this product as a toy; Children under 14 years of age, please use it under the supervision of a guardian.
02. This product is not intended for use by users (including children) with inadequate physiology, perception, mental

ability, experience ,or knowledge, unless used safely under the supervision or knowledge of a person responsible for their safety.

03. Please do not blow directly on the human body for a long time, especially the elderly and children, to avoid physical discomfort.
04. When using, please do not put fingers, sharp objects and metal objects, etc., which will cause product failure and the risk of electric shock, or injury.
05. When using, prohibit the use of wet hands, wet towels and other plugging power to avoid electric shock.
06. This product is not waterproof, please do not use water to directly rinse the product or in the bathroom, heavy moisture, water storage places to use; surface water, please dry in time to dry before trying to turn on the use; completely soaked and internal water into the prohibition of re-use.
07. Do not cover the air outlet and air inlet, such as hanging clothes, towels, clothes, and other items, so as not to cause product failure.
08. Prohibit the use and storage in high temperature (higher than 60 °C) environments and confined spaces, such as greenhouses, construction sites, fireplaces, exposed car rooms and other environments, which will cause plastic deformation, flame with the wind to cause fire, battery explosion and other failures and accidents.
09. Do not squeeze, disassemble the battery or place the battery in a high-temperature environment (60°C and above) for a long time, otherwise there may be a risk of liquid leakage or explosion.
10. If consumers use the power adapter to charge, the power adapter input rated voltage and current should be within 5.0V $\pm$ 2.0A, and the national mandatory safety certification

before use.

11. This product uses lithium-ion battery, no memory function, overcharge or overdischarge will affect the service life of the product, please charge in time and disconnect the power after full charge, long time (more than 3 months) do not use please fully charge.
12. If there is smoke, fire and other failures in use, please immediately turn off the power to stop using, and send it to the dealer or manufacturer to deal with, do not disassemble themselves to avoid danger.
13. Do not bend or pull the power cord during charging to avoid poor contact.

Product Parameters

Brand: JisuLife

Product Model: FA14

Product Name: Neck Fan Life3

Input: 5.0V $\equiv$ 2.0A

Battery Capacity: 4000mAh(14.8Wh/3.7V)

Battery Cell: Lithium-ion Battery

Charging Time: 3.5-4.5h

Operating Time: 2-13.5h(depending on different gears/use scenarios)

Product Weight: about 270g

Product Size: 206×200×60mm

Packing Accessories

Neck Fan Life3 * 1

USB-C Charging Cable * 1

Manual * 1

The contents in this user manual and the technical specification of the product will be changed without prior notice.

www.sunnysoft.cz

Manufacturer: Shenzhen Jisu Technology Co., Ltd

Address: 301, Building A, No.8, Changjiangpu 2 Road, He'ao Community, Yuanshan Street, Longgang District, Shenzhen

URL: www.jisulife.com

Tel: 400-011-8812



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

"NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."