

Tripod Selfie Stick

(Wireless Version)


Quick Start Guide

Connecting to your phone

① Press and hold the camera button on the selfie stick for 2 seconds to enter Bluetooth pairing mode.

② Enable Bluetooth on your phone search for available devices. Select AF15.

If the selfie stick successfully pairs with your phone, the green indicator will be on for 3 seconds and off.




English

Using the selfie stick



① Expand the selfie stick.




② (Optional) Open the tripod at the bottom, push the pole upwards, and place the tripod on a horizontal level surface.



- ③ Attach your phone on the selfie stick.



- ④ Set the volume button on your phone to act as the shutter button.
Use the remote control to take a photo.



English

Replacing the remote control battery


Remove the Bluetooth remote control from the tripod. Push against the battery cover in the direction shown by the arrow and replace the battery.



1



2



3

Powering off the selfie stick

Press and hold the camera button on the selfie stick for 3 seconds until the green indicator light turns off.

Note:

- If you do not use the remote control for 3 minutes, it will automatically enter sleep mode and disconnect from your phone. The remote control will be powered off if you do not use it for 6 hours.
- The Bluetooth range for the remote control is 10 meters.
- When you are using the selfie stick, the red indicator of the selfie stick will blink if the battery level is lower than 20%. Please replace the battery in time.

The statements should be displayed in the user manual:
changes or modifications not expressly approved by the party responsible for compliance
could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.