Please read the manual carefully before using this product.


Thank you for your purchase and use of XGIMI products, for your safety and interests, please read the manual carefully before using this product. If you are not in accordance with the product manual operati on or attention, resulting in any personal injury, property or other losses, XGIMI will not be liable.

About the manual (hereinafter referred to as "manual")

The copyright belongs to XGIMI; The trademarks and trade names mentioned in the manual belong to their respective owners; if the manual is inconsistent with the actual product, the actual product shall prevail in kind.


If you have any objection to the contents or terms of the manual, please submit a written objection within seven days after the purchase, otherwise you have agreed to understand and accept all the contents of the manual.

Chengdu XGimi Technology Co.,Ltd.



1 Turn ON/OFF

 Slide the lens cap to turn on the device . Close the lens cap and wait for the indicator light off,




2 Remote Control Pairing

 Please place remote control within 10cm from the device, Press " ጏ " and " 습 " at the same time, when the indicat light flashes, then release the buttons, the indicator light flashes continuously, after hearing "Ding" sound,

 If pairing failed, exits the pairing mode after 30 seconds timeout, follow the steps above to pair again.

3 Auto Focus/Remote Control Focus

pictures will be adjusted automatically with the moving



 Slip the Function key of remote control to the right to enable the focusing function, and press " Volume+/- " key to adjust the focus.




4 Bluetooth Speaker Mode




Volume- Next Play/Pause Previous Volume+

Enter Bluetooth speaker mode


In shutdown mode, press the " > button on the device to enter the Bluetooth speaker mode. In projection mode, press the "@" button on the remote control, and select the speaker mode in the menu to enter the Bluetooth speaker mode.



Quit Bluetooth speaker mode











Quit Bluetooth speaker mode








Usage of Bluetooth speaker mode

- After entering the Bluetooth speaker mode, the
- When the device is under the Bluetooth speaker mode, use your phone to search the device via your phone can be played.
- *when the songs are playing via Bluetooth, the button on the device is invalid.
- play songs via Bluetooth, you could disconnect the current connection of the phone or double click the " » I " button on the device to enter into reconnect
- When the device disconnects with the phone via Bluetooth, it the device will automatically play downloaded songs.

5 Charge Description

- using of battery power supply, the top indicator of the
- Please use the official standard power adapter to



 $^{\odot}$

%

(OK

5 6

XGIMI

ON/OFF

Air Mouse

Menu/Shortcut (*Long Press

Directions & OK

(*Focal Length+)


Volume-

(*Focal Length-)

Function Key

VOL Focus

- . When you need to other mobile phones want to to
- When the device is in the charging process or the



6 XGIMI Assistance

- · mobile phone remote: devic can be easily controlled by mobile phone.
- · mobile phone resource: send the resource from mobile phone to device to view photos or videos.
- mirroring display control; mirroring to mobile phone. support gravity sensor games.

7 More Functions

System Upgrade

- Online Upgrade Online upgrade through system settings
- Local Upgrade
 Copy the firmware to the packing list of U disk in FAT32 format Insert the U disk into the USB2.0 interface and
- select the U disk upgrade. Forced upgrade 1. Copy the firmware to the packing list of USB disk in FAT32 format.
- The lens cap keeps closing and Insert the USB disk into the USB2.0 port.
- 3. Plug in power adapter, then press the " " and " "> " button at the same time. 4. Slip the lens cap, wait for three seconds, and elease the " K " and " »I " button, the device will enter to the forced upgrade mode.

System Function

. The manual provides instruction of basic functions. check the electronic instructions on the main page:

Usage Notice

How to use the equipment correctly:

- . Do not turn the lens towards the human eyes to avoid the
- . Do not block the air inlet and outlet of the device to avoid
- damage to the internal electronic devices. . Do not use paper, cloth, and other cleaning tools to wipe the lens directly to avoid damage to the lens; use clean air
- blowing to remove dust on the lens' surface. . Do not use chemicals, cleaning agents or clean water to
- mineral liquid corrosion circuiting board. Please put the device and its parts and accessories in the
- place where children cannot touch. Please ensure that the device is being used in a dry and
- Do not store the device in hot or cold environment, high (low) temperature will shorten the life span of electronic devices.
- Enabling operating environment could be 0~40°C. . Do not put the device in any heating equipment
- (such as drying machine, microwave oven, and etc.) Do not squeeze the device or place heavy objects on the device to avoid damage to the device.
- resulting in damage to the internal circuit board. Do not attempt to disassemble device. If you have any
- questions, please contact the after-sales service of XGIMI. Do not maintain any products. If the device or any parts
- If the device has not been using for a long time, please cut off the power supply.

after-sales service or factory repair.

Product specification

coded format)

horizontal: ±30 degree

Quad-core 1.5GHz
Mail-T720MP2
1GB DDR3

Forward/backward/hang ceiling

This device complies with Part 15 of the FCC Rules. Operation

(1) this device may not cause harmful interference, and (2) interference that may cause undesired operation. The user radiator shall caution the user that changes or modifications could void the user's authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the manual in that alternative form, provided the user can reasonable be expected to have the capability to access information in that

FCC Warning

furnished the user shall include the following or similar statement placed in a prominent location in the text of the manual: NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

-- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receive -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits

C∈ RoHS

FCCID: 2AFENG03V

